



TEHNOMAT, KRANJ, d.o.o.
Jezerska cesta 55, 4000 KRANJ, SLOVENIA
Phone: +386 4 2351810 • Fax: +386 4 2351811
info@tehnomat.si • sales@tehnomat.si

INSTRUCTIONS FOR INSTALLATION OF SILENT TIP

For mounting all kinds of ferrules, tips and grips onto the pole shafts we recommend the use of hot melt glue.

1. Environment temperature should be above 21C°.
2. The end of the pole shaft (approx. last 6 cm which will be glued) must be a bit rough – use sandpaper grade 600.
3. Remove all dust from the sanded surface and clean it with nitro → the shaft it will be degreased at the same time.
4. Warm up the end of the pole shaft with hot air gun (temperature upto 70°C – 80°C).
5. Apply hot-melt glue directly into the hole of the silent tip.
6. Push the warmed-up pole end into the glued tip hole and turn it a few times, so the glue will spread over the entire surface of the inserted part of the pole shaft (pay attention to the right direction of the carbide tip insert).
7. Keep pressing the tube into the tip hole a few more seconds until glue starts to cool down.
8. A slightly warm hard plastic shell of the silent tip is an indicator of a correctly performed procedure - the silent tip will be firmly mounted onto the pole shaft.
9. Any possible excess glue should be removed after the shaft and tip cool down completely.